



CARE & USE

Thank you for your purchase of The CleanCut Door™. CleanCut has prepared these standard care and use instructions for the The CleanCut Door™. Please feel free to contact the installer of this product or CleanCut, with any questions you may have. Thank you for your purchase of The CleanCut Door™!

- *Do not use the tub, open the door or apply weight to The CleanCut Door™ for two (2) days after installation to allow for the CleanCut Tub Door's adhesive to completely dry.*
- *Prior to first use, please inspect the bead of caulk around the perimeter of the The CleanCut Door™ to ensure that a continuous caulk bead has been applied and that there are no cracks or areas where caulk is absent. Conduct a similar inspection of the perimeter adhesive every six (6) months thereafter.*
- *Prior to first use, please clean and rinse the bathtub to rid the area of any dust and/or particulates that may remain after installation.*
- *Prior to first use, please wipe The CleanCut Door™ and inner seal thoroughly. It is recommended that the unit be cleaned regularly with a gentle household cleaning agent. Do not use harsh cleansers or abrasive tools to clean The CleanCut Door™ .*
- *Safeway recommends a multi-purpose foam cleaning pad to remove any spots.*
- *Do not bear weight on The CleanCut Door™ handle or door and do not use the unit as a grab-bar or assistive device.*
- *During use, do not unlatch The CleanCut Door™ handle or open the door once water has been added to the bathtub.*
- *After the adhesive has cured, we recommend leaving the door unlatched while not in use.*
- *As with any bathtub, children should not be left unattended in the bathtub.*

Safeway Safety Step, LLC, DBA CleanCut
5242 Rialto Road
West Chester, OH 45069